

UKCE A GARAGE Manby Business Park, Manby, Lincolnshire, LN11 8UT Lumineux is a B&T Associates Ltd company.

Technical Helpline: +44 (0)1507 328031

www.lumineux.co.uk



## Draycote Emergency Twin Spot Self-Test



#### DISPOSAL

Disassembly instructions for end of life disposal available on website.

Disposal of Electronic Equipment WEEE Directive 2002/96/EC This product falls within the scope of the Waste Electrical & Electronic Equipment Directive (WEEE), which means the product should not be disposed of as normal household waste. Please recycle where facilities exist or check with your Local Authority. RoHS – All components and materials used in this product are RoHS 2002/95/EC compliant.

Specifications may change from time to time. The information contained in this leaflet is for guidance only and should not be considered as always accurate and should be treated as not representative.

#### WARRANTY

This luminaire is warranted for a period of 5 years from the date of purchase\*\*. The backup battery pack in the emergency version is warranted for a period of 24 months. The warranty could be invalidated should the light fitting not be installed according to these instructions, outside the scope of the specification or the product has been altered or tampered with in any way. Please see website for terms and conditions.

#### PRODUCT TEMP SPECIFICATION

Emergency 0 to +30°C

	Part No.	Description	n l	Watts	L(mm)	W (mm)	H (mm)	Weight	,	W	н	
of	410256	Draycote Emerge Twin Spot Self-Tes		6W	301	280	90	0.92Kg			<b>Z</b>	Emerge accorda
ch										0		<ol> <li>Conn</li> <li>For the uninter to the ensur const batter</li> </ol>
~												4. Conn "Swite
n C												5. There to be
me d												6. Follov charg greer
	Installat	Installation Engineers Contact Details:						Luminaire Reference / Location			on	7. Pleas
	Name:		Tel:									
	Luminair	arge Duration <b>24 Hours</b> Eme			Emergency Duration <b>3 Hours</b>			Lamp Type <b>LED</b>				

DRAYCOTE EMERGENCY TWIN SPOT SELF-TEST DIMENSIONS

ROUTINE TEST RECORD											
Type Test	Year 1		Year 2		Year 3		Year 4		Year 5		
	Signed	Date									
Functional 1											
Functional 2											
Functional 3											
Functional 4											
Functional 5											
Functional 6											
Functional 7											
Functional 8											
Functional 9											
Functional 10											
Functional 11											
3hr Duration 12											

# Wiring instructions for units equipped an with EMERGENCY function

### mergency lighting luminaries must be installed and maintained in ccordance with the emergency lighting standard BS 5266-1

- I. Connect incoming earth cable to 'Earth' terminal on connector block.
- 2. Connect incoming neutral cable to 'Neutral' terminal on connector block.
- 3. For the emergency unit to work correctly, please ensure that an uninterrupted permanent live feed is present and is connected directly to the 'Permanent Live' terminal of the mains terminal block. Please ensure there are no switches, PIRs etc within the permanent live feed, constant switching of the emergency pack could result in premature battery failure.
- 4. Connect incoming switched live cable to the terminal marked "Switched Live"
- i. There should be a loose flying lead connected to the battery. This needs to be attached to the socket from the emergency control unit.
- 6. Following power up the green LED indicator should illuminate to indicate charging. If power to the unit is disrupted or isolated, the unit indicating green LED will switch off, triggering the emergency LEDs to illuminate.
- 7. Please allow 24 hours charge before first emergency test.

This product contains a light source of energy efficiency Class G.