
Installation Instructions: Wall Light (10450/10452)



gualified electrician ensuring the installation complies with current IEE wiring regulations BS7671:2018 & local building control.

• BELL will not accept responsibility for any claims arising from a poor installation.

BELLlighting

Important User Advice

- The ambient temperature should not exceed -30°C to +35°C
- Ensure that there is adequate free air ventilation around the fitting
- Always switch off mains supply before installing.

This product may contain substances that can be hazardous to the environment if not disposed of properly. Electrical and electronic equipment should never be disposed of with general household waste but must be separated for its correct treatment and recovery.

Where possible recycle your packaging.

Technical Helpline +44 (0)1924 893380 www.**belllighting**.co.uk

British Electric Lamps Ltd Unit A Foxbridge Way, Normanton Industrial Estate Normanton, West Yorkshire. WF6 1TN

T: +44 (0)1924 893380 F: +44 (0)1924 894320 E: sales@belllighting.co.uk

www.belllighting.co.uk