

Installation Instructions: LED T8 Tube (60200/1/2/3/4)

| Date | Revision |
|----------|----------|
| 1.6.2022 | 2 |

Read these instructions before installation and retain for future reference This equipment should be installed by a competent electrician 

Important Information




We recommend that luminaires are installed by a qualified electrician ensuring the installation complies with current IEE wiring regulations BS7671:2018 & local building control.

- BELL will not accept responsibility for any claims arising from a poor installation.
- The light source of this luminaire is not replaceable: when the light source reaches end of life, the whole luminaire must be replaced.
- Always switch off mains supply before installing.

This product may contain substances that can be hazardous to the environment if not disposed of properly. Electrical and electronic equipment should never be disposed of with general household waste but must be separated for its correct treatment and recovery. Where possible recycle your packaging.



WARNING
This fixture has been modified, use only LED Tubes



Installation - Retro fit version

- 1: Switch off the electricity supply
- 2: Remove the conventional lamp.
- 3: Remove the starter.
- 4: Stick the warning label in a visible location
- 5: Click the LED replacement starter into the starter holder.
- 6: Insert the LED Tube into the lampholder.
- 7: Secure the position by turning the lamp by 90°.
- 8: Switch on electricity and check for lamp operation.

| Product | Specification | Qty |
|-----------------|---------------|-----|
| T8 LED | LED T8 Tube | 1 |
| Starter | LED Starter | 1 |
| 220-240V / 50Hz | | |

Technical Helpline +44 (0)1924 893380
www.bellighting.co.uk

British Electric Lamps Ltd, Unit A Foxbridge Way
Normanton Ind Est, Normanton, West Yorkshire. WF6 1TN
T: +44 (0)1924 893380 F: +44 (0)1924 894320 E: sales@bellighting.co.uk