

Date	Revision
31.5.2024	1

Read these instructions before installation and retain for future reference This equipment should be installed by a competent electrician



Important Information

We recommend that luminaires are installed by a qualified electrician ensuring the installation complies with current IEE wiring regulations BS7671:2018 & local building control.

- All tests should be carried out in accordance to EN 50172:2004.
- BELL will not accept responsibility for any claims arising from poor installation.

Important User Advice

- The ambient room temperature should not exceed 35°C.
- Ensure that there is adequate free air ventilation around the fitting.
- Always switch off mains supply before installing.

This product may contain substances that can be hazardous to the environment if not disposed of properly. Electrical and electronic equipment should never be disposed of with general household waste but must be separated for its correct treatment and recovery. Where possible recycle your packaging.




mm² ←→ 1.5-2.5 12











British Electric Lamps Ltd

BELL House, Foxbridge Way, Normanton Industrial Estate Normanton, West Yorkshire. WF6 1TN



Date	Revision
31.5.2024	1

Read these instructions before installation and retain for future reference This equipment should be installed by a competent electrician



Important Information

We recommend that luminaires are installed by a qualified electrician ensuring the installation complies with current IEE wiring regulations BS7671:2018 & local building control.

- All tests should be carried out in accordance to EN 50172:2004.
- BELL will not accept responsibility for any claims arising from poor installation.

Important User Advice

- The ambient room temperature should not exceed 35°C.
- Ensure that there is adequate free air ventilation around the fitting.
- Always switch off mains supply before installing.

This product may contain substances that can be hazardous to the environment if not disposed of properly. Electrical and electronic equipment should never be disposed of with general household waste but must be separated for its correct treatment and recovery. Where possible recycle your packaging.



mm² ←→ 1.5-2.5 12













Replace LED module	Replace the driver	LED -
Replace LED module	Replace the driver	

British Electric Lamps Ltd

BELL House, Foxbridge Way, Normanton Industrial Estate Normanton, West Yorkshire. WF6 1TN



Date	Revision
31.5.2024	1

Read these instructions before installation and retain for future reference This equipment should be installed by a competent electrician



Important Information

We recommend that luminaires are installed by a qualified electrician ensuring the installation complies with current IEE wiring regulations BS7671:2018 & local building control.

- All tests should be carried out in accordance to EN 50172:2004.
- BELL will not accept responsibility for any claims arising from poor installation.

Important User Advice

- The ambient room temperature should not exceed 35°C.
- Ensure that there is adequate free air ventilation around the fitting.
- Always switch off mains supply before installing.

This product may contain substances that can be hazardous to the environment if not disposed of properly. Electrical and electronic equipment should never be disposed of with general household waste but must be separated for its correct treatment and recovery. Where possible recycle your packaging.



mm² ←→ 1.5-2.5 12











7





British Electric Lamps Ltd BELL House, Foxbridge Way, Normanton Industrial Estate

T: +44 (0)1924 893380 F: +44 (0)1924 894320 E: sales@belllighting.co.uk

Normanton, West Yorkshire. WF6 1TN



Date Revision 31.5.2024

Read these instructions before installation and retain for future reference This equipment should be installed by a competent electrician



Important Information

We recommend that luminaires are installed by a qualified electrician ensuring the installation complies with current IEE wiring regulations BS7671:2018 & local building control.

- All tests should be carried out in accordance to EN 50172:2004.
- BELL will not accept responsibility for any claims arising from poor installation.

Important User Advice

- The ambient room temperature should not exceed 35°C.
- Ensure that there is adequate free air ventilation around the fitting.
- Always switch off mains supply before installing.

This product may contain substances that can be hazardous to the environment if not disposed of properly. Electrical and electronic equipment should never be disposed of with general household waste but must be separated for its correct treatment and recovery. Where possible recycle your packaging.


















Replace LED module Replace the driver

British Electric Lamps Ltd

BELL House, Foxbridge Way, Normanton Industrial Estate Normanton, West Yorkshire. WF6 1TN