


Important Information

We recommend that luminaires are installed by a qualified electrician ensuring the installation complies with current IEE wiring regulations & local building control.





- BELL Lighting will not accept responsibility for any claims arising from poor installation.
- The operating temperature should be between -20 and 35°C.
- Ensure that there is adequate free air ventilation around the fitting.
- Always switch off mains supply before installing.
- Mount to a stable, secure surface that is rated for the weight of the luminaire.
- Ensure all earth connections are secure, and the floodlight is effectively grounded.
- Not suitable for ATEX hazardous zones (explosive atmospheres).
- To ensure optimum performance, keep the front diffuser clean. Wipe with a soft, damp lint free cloth. Do not use soaps, detergents, solvents or abrasive materials.
- Not intended for use by children.



This product may contain substances that can be hazardous to the environment if not disposed of properly. Electrical and electronic equipment should never be disposed of with general household waste but must be separated for its correct treatment and recovery. Where possible, recycle your packaging.



This luminaire contains a light source with Energy Rating E



For best results use with PIR Sensor 72034, refer to instructions for wiring and configuration settings.

British Electric Lamps Ltd
BELL House, Foxbridge Way, Normanton Industrial Estate
Normanton, West Yorkshire. WF6 1TN

BELL Ireland
Marina House, Clarence Street, Dun Laoghaire
County Dublin, Ireland, A96 AX76

Technical Helpline +44 (0)1924 893380

Technical@belllighting.co.uk

T: +44 (0)1924 893380 F: +44 (0)1924 894320
E: sales@belllighting.co.uk

www.belllighting.co.uk