

# Light Control Sensor (Photocell)

Code: 70408

**Read these instructions before installation and retain for future reference.  
This equipment should be installed by a competent electrician**



## Important Information

**We recommend that luminaires are installed by a qualified electrician ensuring the installation complies with current IEE wiring regulations BS7671:2018 & local building control.**

- All tests should be carried out in accordance to EN 50172:2004.
- BELL will not accept responsibility for any claims arising from poor installation.

## Important User Advice

- The ambient temperature should not exceed 40°C.
- Ensure that there is adequate free air ventilation around the fitting.
- Always switch off mains supply before installing.

This product may contain substances that can be hazardous to the environment if not disposed of properly. Electrical and electronic equipment should never be disposed of with general household waste but must be separated for its correct treatment and recovery. Where possible recycle your packaging.



## Specification

Power source: 220V-240V/AC

Power Frequency: 50/60Hz

Rated Current: 10A

Ambient Light: <10LUX(on) / >40LUX(off)

Working Temperature: -20°C~+40°C

Working Humidity: <93%RH

## Installation

Switch off the power.

Connecting the wire as per the diagram opposite.

Please install the item with the correct orientation.

Switch on the power.

When you test in daytime, you should cover the product.

The light comes on.

The Photocell should be mounted in a clear un-shaded area, away from any artificial light.

