
# LEV71932







#### ON/OFF button

OFF mode: Turns the light off.

ON mode: Turns the light on, sensor starts work and the

settings go to the last program setting.

#### Disable button

Disable mode: Turns off the sensor, light becomes a standard fitting. To reset, press ON/OFF button or switch off/on using wall switch

#### **Reset button**

Reset mode: Press once to reset the sensor back to DIP switch settings

#### **Detection Area**

Set up detection area: 25%/50%/100%

#### **Hold Time**

Set up hold time: 5s/90s/10min/30min/60min/3hr

(Refers to the time period the luminaire remains at 100% illumination after no motion detected)

#### Dim Time(Dim level)(standby period)

Set up hold time dim level: 5min/30min or + ∞(infinity)

#### Dim level %

Set up dim level: 10%/25%/50%

## **Daylight Sensor**

Set up daylight threshold: 15lux/50lux/disable

(When set to 'Disable' mode, the sensor will switch on the luminaire when motion is detected regardless of ambient light levels.

The daylight sensor will only operate when the luminaire is off.)


## Battery: 1 x 3V CR2025L

# Sensor factory default settings:


### DIP settings are:

(Detection area: 100%, Hold Time: 5S, Stand-by

Period: 0S, Stand-by dim level:20%, Daylight Sensor: Disable)



3.Daylight Sensor	ON		5	6	
I: Disable II:50 Lux (Twilight) III:15 lux(Twilight) IV:5 Lux (Dark)		I	ON	ON	Disable
		II	ON	-	50 Lux
		Ш	-	ON	15 Lux
		IV	-	-	5 Lux



4.Standby period*	ON		7	8	
: 0 seconds	▲	-1	ON	ON	0s
II:5 minutes III:30 minutes IV:+ ∞(infinity)	ТШ	II	ON	-	5 min
		III	-	ON	30 min
	-	IV	-	-	+ ∞

