

Installation Instructions

Rydal Wallpack Tri-Wattage 3CCT

Input	220-240VAC 50/60Hz
Power	15W/22W/30W
Operating Temp	Std -20°C--+45°C
Connection Type	4 Pin Push terminal
Emergency Option	(430948) E3
Control Connection	*
Light Source Energy Rating	C



Box Contents:

- Wallpack
- Fixing Kit
- Instruction Manual


Tools Required For Installation:

- Drill
- Screwdriver



Dimensions:

Part No.	Description	L (mm)	W (mm)	H (mm)	Weight
431139	Rydal Wallpack 3CCT Tri-Wattage	248	225	108	2.5Kg



End Of Life Disposal:

Disassembly instructions for end of life disposal available on website.
Disposal of Electronic Equipment WEEE Directive 2002/96/EC This product falls within the scope of the Waste Electrical & Electronic Equipment Directive (WEEE), which means the product should not be disposed of as normal household waste. Please recycle where facilities exist or check with your Local Authority. RoHS - All components and materials used in this product are RoHS 2002/95/EC compliant. Specifications may change from time to time. The information contained in this leaflet is for guidance only and should not be considered as always accurate and should be treated as not representative.



READ THESE INSTRUCTIONS THOROUGHLY BEFORE INSTALLATION
KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

IMPORTANT:

This product must be installed by a qualified electrician or competent person, and in accordance with current building and IET wiring regulations.

Warranty:

This luminaire is warranted for a period of 5 Years from the date of purchase**. The backup battery pack in the emergency version is warranted for a period of 5 Years. The warranty could be invalidated should the light fitting not be installed according to these instructions, outside the scope of the specification or the product has been altered or tampered with in any way. Please see website for terms and conditions.



WARNING: Risk of electric shock!

Isolate the mains power before proceeding.

- Turn off the mains power before performing inspections, installation, or removal
- Verify that the supply voltage is correct by comparing it with the luminaire label information
- It is the installers responsibility to ensure installation is suitable for the total load of the luminaire(s). The supply cable, fuses/circuit breakers must be correctly rated for the electrical load and considering for any transient inrush currents that may occur.
- Do not perform insulation strength or resistance tests on installed luminaire(s) connected

Wiring instructions for units equipped with EMERGENCY function:

Emergency lighting luminaires must be installed and maintained in accordance with the emergency lighting standard BS 5266-1

- For the emergency unit to work correctly, please ensure that an uninterrupted permanent live feed is present and is connected directly to the 'Permanent Live' terminal of the mains terminal block. Please ensure there are no switches, PIRs etc within the permanent live feed, constant switching of the emergency pack could result in premature battery failure.
- Following power up the green LED indicator should illuminate to indicate charging. If power to the unit is disrupted or isolated, the unit indicating green LED will switch off, triggering the emergency LEDs to illuminate.
- When self-test mode is selected, 24hrs from connection to mains power, a 3hrs duration test will be performed automatically.

Installation Procedure:

1. Make sure to check the mains power is off before any installation. Remove the Two screws securing the lid to the base. Lift up as shown to disengage lid & base.
2. Disconnect yellow input connector, & also metal securing wire to completely remove .
3. As shown the Four mounting holes for installation.
4. Loosen Cable clamp screws, Install Input power cable through clamp to 4 pin connector Brown (L) to L1 Live, Earth Green/yellow to Earth, Blue (N) Neutral.
5. Once input power cable is connected, re-tighten clamping screws Diagram for standard wiring & Emergency wiring. Re-connect yellow input cable and re-attach metal securing wire.
6. Re-attach Lid, close securely checking for any wiring not to be trapped Lid should sit flush, now add the two screws and tighten.
7. Wallpack should sit flush to wall as shown, upwards/downwards.
8. Connect power and turn on , to illuminate the luminaire.

