

**READ THESE INSTRUCTIONS THOROUGHLY BEFORE INSTALLATION KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

**IMPORTANT:**

This product must be installed by a qualified electrician or competent person, and in accordance with current building and IET wiring regulations.

**BOX CONTENTS**

This lighting fixture has been properly packed to avoid damage during transit. Before commencing with the installation carefully inspect the luminaire to confirm there is no damage. **DO NOT INSTALL** if any damage has occurred to the fixture or any of its components.

- Light Fitting
- Instruction Manual


**TOOLS REQUIRED**



- Drill



- Cable



**INSTALLATION INSTRUCTIONS**

<p><b>1</b></p>	<p><b>2</b></p>	<p><b>3</b></p>
<p><b>4</b></p>	<p><b>5</b></p>	<p><b>6</b></p>

**PLEASE READ THESE INSTRUCTIONS BEFORE INSTALLATION.**



**WARNING: Risk of electric shock! Isolate the mains power before proceeding.**


- Turn off the mains power before performing inspections, installation, or removal
- Verify that the supply voltage is correct by comparing it with the luminaire label information
- It is the installers responsibility to ensure installation is suitable for the total load of the luminaire(s). The supply cable, fuses/circuit breakers must be correctly rated for the electrical load and considering for any transient inrush currents that may occur
- Do not perform insulation strength or resistance tests on installed luminaire(s) connected

1. Disconnect the main power supply and cut your required size mounting hole. (See reverse for correct size)
2. Connect the LED driver to the mains supply as per wiring diagram and select required power
3. Connect the LED driver to the downlight using the Twist-N-Lock jack connector
4. Select required CCT setting
5. Fit the downlight into desired location lifting the fixing levers before installation
6. Re-connect the mains supply

**DO NOT COVER PRODUCT OR CONTROL GEAR WITH INSULATION OR OTHER MATERIALS**

## TUNSTALL DOWNLIGHT DIMENSIONS

Part No.	Description	Watts	L (mm)	W (mm)	H (mm)	Hole Cut-Out	Weight
430695	Tunstall 4" Dual Wattage Downlight	6W & 8W	120	120	55	105mm	0.24Kg
430696	Tunstall 6" Dual Wattage Downlight	10W & 15W	170	170	69	150mm	0.37Kg
430697	Tunstall 8" Dual Wattage Downlight	20W & 30W	230	230	79	210mm	0.59Kg



### DISPOSAL

Disassembly instructions for end of life disposal available on website.

Disposal of Electronic Equipment WEEE Directive 2002/96/EC This product falls within the scope of the Waste Electrical & Electronic Equipment Directive (WEEE), which means the product should not be disposed of as normal household waste. Please recycle where facilities exist or check with your Local Authority. RoHS - All components and materials used in this product are RoHS 2002/95/EC compliant.

Specifications may change from time to time. The information contained in this leaflet is for guidance only and should not be considered as always accurate and should be treated as not representative.

Installation Engineers Contact Details:		Luminaire Reference / Location
Name:	Tel:	

Luminaire Details:	Full Recharge Duration <b>24 Hours</b>	Emergency Duration <b>3 Hours</b>	Lamp Type <b>LED</b>

### WARRANTY

This luminaire is warranted for a period of 3 years from the date of purchase\*\*. The backup battery pack in the emergency version is warranted for a period of 12 months. The warranty could be invalidated should the light fitting not be installed according to these instructions, outside the scope of the specification or the product has been altered or tampered with in any way. Please see website for terms and conditions.

### PRODUCT TEMP SPECIFICATION

Standard 0 to +40°C

Emergency 0 to +30°C

Revision 1.0 - October 2022

\*\* Please see our website for more detailed information on warranty.

This product contains a light source of energy efficiency Class F.

Technical Helpline: +44 (0)1507 328031